

Design Engineering, Inc.

604 Moore Road
Avon Lake, OH 44012



THERMAL TUNING PRODUCTS

Installation Instructions

DEI Speed Sleeve™

PART NO. 010114 through 010115

KIT CHECKLIST - 4 & 6 Cyl	
12ft	Exhaust Wrap Material
40	Exhaust Wrap Fastener
6	Stainless Steel Locking Ties - 8"

KIT CHECKLIST - 8 Cyl	
16ft	Exhaust Wrap Material
50	Exhaust Wrap Fastener
8	Stainless Steel Locking Ties - 8"

DIRECTIONS

- 1 - Do not start with a hot engine! Allow ample amount of time to cool.
- 2 - Cut material to desired length plus two inches for the fold under (hem). Cut even with the stitching path, this will allow for a straight cut.
- 3 - Place exhaust material around the exhaust tubing that will be wrapped.
- 4 - Fold each end of the material 1/2" to 1" on both ends inward, toward the tubing. Keep folding inward until wrap is even and pretty tight around the tubing.
- 5 - Fold the exhaust wrap material inward at the top and bottom of sleeve so no cut edges are showing.
- 6 - Apply exhaust wrap fastener to the folded end of the wrap placing the teeth portion of the locking fastener around the folded section. Make sure to put both ends of the material in the crimp/fastener together. Do the mid part of the tube first, leaving space at the flange for the locking tie.
- 7 - Use a set of pliers to crimp the fastener in the desired location.
- 8 - Secure the material in place using an 8" Stainless Steel Locking Tie towards the upper part of the exhaust manifold or header towards the flange. This will prevent the material from sliding down the exhaust manifold or header.
- 9 - Continue to crimp each fastener 3" - 4" apart from one another and continue the same process for each tubing.

