



## INSTALLATION INSTRUCTIONS

### Boom Mat Hi-Temp Spray Adhesive

**KIT CONTENTS:**

#010490 - (1) 10oz Hi Temp Spray Adhesive

**NOTES:**

Make sure to spray both surfaces.

**TOOLS:**

None

**SURFACE PREP:**

Vacuum installation area to remove all loose debris. Then clean with isopropyl alcohol, soapy water, or a wax/grease remover. Allow sufficient time to dry before installation of Boom Mat products.

**INSTRUCTIONS:**

1. Point valve toward surface and spray from a distance of 6 to 8 inches.
2. Keep the can moving to avoid a build-up on the surface.
3. Only a thin film is required. Avoid over spraying.
4. For a permanent bond spray both surfaces, allow to tack, then bond.
5. AFTER USE: Clear valve of adhesive by turning can upside down and spraying for at least to seconds.

