



INSTALLATION INSTRUCTIONS

Thank you for purchasing genuine Design Engineering, Inc. products. Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact a certified technician.

DESCRIPTION: Easy Loom

PART NUMBER: 010650, 010651, 010652,
010653, 010654, 010655, 010656, 010657

KIT CONTENTS:

Easy Loom

TOOLS NEEDED:

Scissors

1. Measure the length of Easy Loom™ needed & mark where to cut
2. Use scissors to cut Easy Loom™
3. Wrap Easy Loom™ around lines
4. Cover the end of applied Easy Loom™ with enclosed silicone tape
5. Remove 1" - 2" of plastic backing from tape
6. Wrap tape with 2/3rd overlap
7. Firmly press the end of tape together