



INSTALLATION INSTRUCTIONS

Boom Mat Under Carpet Lite

KIT CONTENTS:

- #050110 - 24" x 54" (9 sq. ft.) Under Carpet Lite
- #050111 - 48" x 54" (18 sq. ft.) Under Carpet Lite
- #050112 - BULK 1 Linear ft. x 54"W Under Carpet Lite
- #050113 - 54" x 72" (27 sq. ft.) Under Carpet Lite

TOOLS:

Scissors or Boom Mat blade lock knife (050216)

NOTES:

Our Hi Temp Adhesive (010490) can be used to secure in place if necessary.

UC Lite is installed with gray side up (dark side up).

SURFACE PREP:

Vacuum installation area to remove all loose debris. Then clean with isopropyl alcohol, soapy water, or a wax/grease remover. Allow sufficient time to dry before installation of Boom Mat products.

INSTRUCTIONS:

1. Making a template will aid in proper and professional installations.
2. Trim Boom Mat Under Carpet Lite to desired size using scissors or knife.
3. After Boom Mat Under Carpet Lite is set in proper location, you may apply spray adhesive (DEI Part #010490) to both the Under Carpet Lite material and the surface it is being installed on to secure in place if desired.



UC Lite trimmed and peeled back awaiting spray adhesive.



UC Lite installed with gray side up.