



INSTALLATION INSTRUCTIONS

Boom Mat Leather Look

KIT CONTENTS:

- #050120 - 24" x 48" (8 sq. ft.) Leather Look Sound Barrier
- #050121 - 48" x 48" (16 sq. ft.) Leather Look Sound Barrier
- #050122 - BULK 1 Linear ft. x 48"W Leather Look Sound Barrier

NOTES:

Our Hi Temp Adhesive (010490) can be used to secure in place if necessary.

TOOLS:

Boom Mat blade lock knife (050216) or snips

SURFACE PREP:

Vacuum installation area to remove all loose debris. Then clean with isopropyl alcohol, soapy water, or a wax/grease remover. Allow sufficient time to dry before installation of Boom Mat products.

INSTRUCTIONS:

1. Making a template will aid in proper and professional installations.
2. Trim Boom Mat Leather Look Sound Barrier to desired size using scissors.
3. After Boom Mat Leather Look Sound Barrier is set in proper location, you may apply DEI Hi-Temp Spray Adhesive (DEI part # 010490) to both the Boom Mat Leather Look material and the surface it is being installed on to secure in place if desired.

