



## INSTALLATION INSTRUCTIONS

### Boom Mat Spray-On

**KIT CONTENTS:**

#050220 – (1) 18oz Boom Mat Spray On Can

**NOTES:**

Use drop cloth or newspapers to protect surrounding areas from spray mist.

**TOOLS:**

None

**SURFACE PREP:**

Clean and dry surface thoroughly before spraying. Remove, wax, grease, dirt, etc. before applying.

**INSTRUCTIONS:**

1. For best results, use when can is between 70°F and 90°F
2. Shake can vigorously for at least one minute after rattle is heard and occasionally during use to insure uniformity and to prevent clogging.
3. Point opening of spray button toward desired application, holding can 12 to 18 inches from the surface to be coated.
4. Press spray button firmly. Use short, steady, even strokes while spraying.
5. If clogging develops, turn spray button 1/4 turn. If clogging persists, remove and clean spray button.
6. To clean spray button for future use, turn can upside down and spray can for two seconds.