

**Design Engineering, Inc.**

604 Moore Road  
Avon Lake, OH 44012



**Installation Instructions**

**DEI Cool Cover™ Air Tube Kit**

PART NO. 010417

| KIT CHECKLIST |                          |
|---------------|--------------------------|
| 1             | Air Tube Reflective Wrap |
| 1             | Strip of Reflective Tape |

| NOTE   |
|--|
| It may be necessary to cut wrap for proper length fitment. You will need a sharp knife, razor, or sissors, and a pen with straight edge. |

**DIRECTIONS**

- 1 - Disconnect and remove air tube from engine bay (if installed on vehicle) for ease of installation.
  - 2 - First wrap Cool Cover around air tube to determine proper length and fitment.
  - 3 - After determining appropriate length of Cool Cover, mark where to trim.
- NOTE Be sure to take note of the location of any emission or vacuum lines in air tube or mounting brackets when determining where to trim excess Cool Cover material.
- 4 - As an aesthetics option, use DEI Cool Tape or reflective tape to accent Cool Cover edges.
  - 5 - Simply apply measure length of tape needed, apply to edge and fold over to opposite side for a clean and finished look.
  - 6 - Next match up Velcro stripes and secure.
  - 7 - Reinstall air tube and connect emission and vacuum lines and secure to brackets (if applicable).