



## INSTALLATION INSTRUCTIONS

# Under Hood Thermal Acoustic Lining

### KIT CONTENTS:

#50510 - 32" x 54" (12 sq.ft.) Under Hood Thermal Acoustic Lining

### SURFACE PREP:

Vacuum installation area to remove all loose debris. Then clean with isopropyl alcohol, soapy water, or a wax/grease remover. Allow sufficient time to dry before installation of Boom Mat products.

### TOOLS:

Scissors or snips, Cardboard/Poster board to use as a template

### INSTRUCTIONS:

1. Making a template will aid in proper and professional installation.
2. Using cardboard or poster board trace an outline of the area to be covered. Cut out template and transfer to Underhood Lining.
3. Trim Under Hood to desired size using sharp scissors or snips.
4. Vacuum installation area to remove all loose debris. Then clean with isopropyl alcohol, soapy water, or a wax/grease remover. Allow sufficient time to dry before installation of Boom Mat products.
5. Remove the backing to expose the adhesive and carefully apply to clean and dry desired area.
6. After Under Hood is set in proper location, apply pressure to ensure a strong bond with installation surface.

