



INSTALLATION INSTRUCTIONS

Thank you for purchasing genuine Design Engineering, Inc. products. Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact a certified technician.

DESCRIPTION: 500401 and 500403
1967-1969 Camaro/Firebird complete insulation kit

KIT CONTENTS:
500404, 500405, 500406, 500407, 500409, 50010, 500412.
(500408 optional for coupe)

TOOLS NEEDED:

Scissors

SAFETY:

Safety glasses

Gloves

NOTE OF CAUTION: Wear eye and hand protection when installing all materials.

OVERVIEW: This kit controls heat and sound on the entire 67-69 Camaros and Firebirds

STEP 1. Our DEI complete Camaro consists of individual component kits.

STEP 2. Each component kit includes installation instructions for that kit.

STEP 3. Follow each set of instructions for each kit.

STEP 4. When installing the complete kit we have adjusted the amount of spray adhesive needed.