



## INSTALLATION INSTRUCTIONS

Thank you for purchasing genuine Design Engineering, Inc. products. Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact a certified technician.

**DESCRIPTION:** 2007-UP 170" Ext WB  
Floor Kit

**KIT CONTENTS:**  
3D-Mat 30mm Wall Insulation

**TOOLS NEEDED:**

Cleaner & Degreaser  
Rags/Towels  
Tools for interior panel removal  
Adhesive Spray for overhead sections (#050490)

**SAFETY:**

Safety glasses  
Gloves

**NOTE OF CAUTION:** Wear eye and hand protection when installing all materials. Use cleaners or degreasers in a well ventilated area

# FLOOR

## PLACEMENT OF INSULATION

