

INSTALLING VERSA SHIELD

1. Wrap Versa-Shield around component to be protected with reflective side out to determine proper amount needed.

Mark where to trim excess material and trim with scissors at stitch line. Make necessary relief cutouts in material where needed for wires, cables, lines, etc.

3. Apply to component and press sewn-in black narrow "loop" strips to the 2" wide black "hook" strip sewn on the end of Versa Shield material.

NOTES: Install with hook and loop facing away from the heat source.

- Versa Shield should not make direct contact with exhaust system components.
- Outer reflective shell should not come in direct contact with exposed, unshielded wiring or terminal.
- Allow for at least a 2" air gap between Versa-Shield and heat source. Failure to do so may damage Versa-Shield material.

Rev 06/2024 20610067