

Frequently Asked Questions

DEI Dyno Strap™

How do I install Dyno Strap?

Simply feed the tie downs through the Dyno Strap to protect your material from exhaust burns. If the Dyno Strap needs to be anchored it can be sewn to the tie down or braced at the ends with tape.

What size and temperature can this handle?

Dyno Strap can withstand up to five hundred degrees F direct continuous. It also will withstand two thousand degrees F radiant. It is fire proof and easily cut to length. It is thirty six inches long and five inches wide.