



Installation Instructions

Cryo²™ Adjustable Timer Switch

PART NO. 080203

KIT CHECKLIST	
1	Adjustable Timer Switch
4	Female Connectors + 1 extra
1	10 ft. Red Wire
1	10 ft. Black Wire

NOTE
This switch is designed for placement between the activation switch and the solenoid valve. The "Wide Open Throttle" switch and CryO ² "Adjustable Timer" switch cannot be used simultaneously.

DIRECTIONS

- 1 - Disconnect the battery cables before working with the electrical system of the vehicle.
- 2 - Decide where to mount the switch (firewall, under dash, glove box, console, etc).
- 3 - Attach switch using double-sided tape or mounting screws (not incl.) to secure the unit.
*If retro-fitting with an existing CryO² system, this now replaces the existing switch.
- 4 - Wire according to the diagram below.
- 5 - Reconnect the battery.
- 6 - Test without wasting gas by leaving the tank valve closed. Turn on the activation switch while listening for the clicks of the Adjustable Timer Switch and the solenoid.

