



INNOVATIVE
**HEAT & SOUND
CONTROL**
SOLUTIONS

INSTALLATION INSTRUCTIONS

OPTIONAL CENTER SECTION FLOOR MAT
2022-2025 HONDA PIONEER
PART # 902419

**INSTALLATION QUESTIONS? CONTACT DEI AT 800-264-9472
OR VIA EMAIL AT TECH@DESIGNENGINEERING.COM**

PARTS CHECKLIST

Qty 1 - Center Floor Mat
Qty 3 - Push pins

NOTES

SURFACE PREP

None required

To hold the center floor mat in place, you will need to drill 3 small holes on the center front floor section. One in the top middle and one in each of the bottom corners. To start, place the floor mat in the center section on the front floor with the single drilled hole facing the front of the vehicle. The floor mat is cut to fit exactly in that area. When in it's proper location, mark the floor with a marker through the holes already pre-drilled in the floor mat. (FIG 1)




FIG 1



FIG 2

Before drilling make sure that you do not have anything under the floor that can get damaged by drilling. BE CAREFUL not to drill too deep and damage the drive shaft or any lines. The holes in the mat are placed in a spot to avoid any interference, but it is good to check.

Using a 25/64th drill bit, drill on your marks and through the plastic floor. A good tip is to put a piece of masking tape around the drill bit one inch from the tip. Stop drilling once the tape reaches the top of the floor. (Fig 2)



FIG 3

Once holes are drilled, place floor mat in it's location and push a plastic pin into each hole, and through the floor, and secure floor mat. Fig 3 & Fig 4



FIG 4