

INSTALLATION INSTRUCTIONS

2022-2024 Honda Pioneer 1000-3, 1000-5, & 1000-6

PART #902409

1 - Heat Shield
6 - Nylon push pins

NOTES: On the 1000-6 model, the kit will go under the rear seat instead of the front seat. The install procedure is the same, but the shield gets installed under the rear seat.

SURFACE PREP:

Vacuum or wipe down installation area to remove all loose debris/dust.

TOOLS:

Use manufacturer's suggested tools for seat & panel removal

**INSTALLATION QUESTIONS? CONTACT DEI AT 800-264-9472
OR VIA EMAIL AT TECH@DESIGNENGINEERING.COM**

1. Remove lower front seat following factory instructions. Set aside (Fig 1)
2. Remove the under seat Center and passenger side tray's. Passenger side has push pins holding it in place. (Fig 2)



FIG 1



FIG 2

3. Raise the rear bed using the release lever
(FIG 3)



FIG 3

4. Remove the bolts holding the upper seat pad in place using a 10mm socket and ratchet.
(FIG 4)



FIG 4

5. Lift the upper seat pad out and set aside.
(FIG 5)



FIG 5

6. You will need to remove the plastic panel shown in (FIG 6) (MARKED IN RED). This is held in place with two different styles of plastic push pins. For the style with the larger head, lift up on the center pin, then remove the complete push pin. (Image FIG 7 & FIG 8). The other style push pin has a small center pin that you push in using a small punch or screw driver. (FIG 9)




FIG 6



FIG 7



FIG 8



FIG 9

8. Remove the rear plastic shield and set aside. (FIG 10)




FIG 10




FIG 11

10. Using the new DEI heat shield. Install with the reflective side facing down or towards the engine. The top part of the shield goes under the frame rail and pulled up to go behind the back of the front seat. (See red circle arrow) Align the holes in the shield with the existing holes where the plastic panel mounted and the steel seat base frame. (See red arrows showing factory holes to line up shield with) (FIG 11) When you re-install the plastic panel you will use these holes to keep the shield in place. Use the 6 provided push pins to hold the shield to the metal seat frame. (Circled in red FIG 12)




FIG 12

11 Reverse the order to install the remaining parts.